




# Instructions for Installation, Operation and Maintenance of Breaker Interface Module

(Compatible with Digitrip OPTIM and RMS 810/910 Trip Units and IQ Energy Sentinels)

P R O T E C T I O N   A N D   C O O R D I N A T I O N

P  
O  
W  
E  
R  
Q  
U  
A  
L  
I  
T  
Y

E  
N  
E  
R  
G  
Y  
M  
O  
N  
I  
T  
O  
R  
I  
N  
G



C O M M U N I C A T I O N S   S Y S T E M S

**WARNING**

IMPROPERLY INSTALLING OR MAINTAINING THESE PRODUCTS CAN RESULT IN DEATH, SERIOUS PERSONAL INJURY, OR PROPERTY DAMAGE.

READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE ATTEMPTING ANY UNPACKING, ASSEMBLY, OPERATION OR MAINTENANCE OF THE CIRCUIT BREAKERS.

INSTALLATION OR MAINTENANCE SHOULD BE ATTEMPTED ONLY BY QUALIFIED PERSONNEL. THIS INSTRUCTION BOOK SHOULD NOT BE CONSIDERED ALL INCLUSIVE REGARDING INSTALLATION OR MAINTENANCE PROCEDURES. IF FURTHER INFORMATION IS REQUIRED, YOU SHOULD CONTACT CUTLER-HAMMER.

**WARNING**

THE CIRCUIT BREAKERS DESCRIBED IN THIS BOOK ARE DESIGNED AND TESTED TO OPERATE

WITHIN THEIR NAMEPLATE RATINGS. OPERATION OUTSIDE OF THESE RATINGS MAY CAUSE THE EQUIPMENT TO FAIL, RESULTING IN DEATH, BODILY INJURY AND PROPERTY DAMAGE.

ALL SAFETY CODES, SAFETY STANDARDS AND/ OR REGULATIONS AS THEY MAY BE APPLIED TO THIS TYPE OF EQUIPMENT MUST BE STRICTLY ADHERED TO.

**WARRANTY AND LIABILITY INFORMATION**

NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OF MERCHANTABILITY, OR WARRANTIES ARISING FROM COURSE OF DEALING OR USAGE OF TRADE, ARE MADE REGARDING THE INFORMATION, RECOMMENDATIONS AND DESCRIPTIONS CONTAINED HEREIN. In no event will Cutler-Hammer be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information and descriptions contained herein.

**Cutler-Hammer**

Power Distribution Components Division

Five Parkway Center

Pittsburgh, PA 15220

First Printing:  
May 1996

*All possible contingencies which may arise during installation, operation or maintenance, and all details and variations of this equipment do not purport to be covered by these instructions. If further information is desired by purchaser regarding his particular installation, operation or maintenance of particular equipment, contact a Cutler-Hammer representative.*

## TABLE OF CONTENTS

	Page
<b>SECTION 1: INTRODUCTION</b>	
1-1 Common Terms.....	1
1-2 Preliminary Comments and Safety Precautions.....	1
1-2.1 Safety Precautions .....	1
1-3 Product Overview .....	2
1-4 Features and Functions.....	2
<b>SECTION 2: HARDWARE DESCRIPTION</b>	
2-1 General .....	4
2-2 Operator Panel.....	4
2-3 Rear Access Area .....	5
2-3.1 DIP Switches .....	5
2-3.2 Sub-Network Connector .....	6
2-3.3 PONI Interface Connector (Network) .....	6
2-3.4 Left Rear Chassis.....	7
2-3.5 Right Rear Chassis .....	7
2-4 Power Supplies .....	7
2-4.1 Switchboard Mounted Power Supply .....	7
2-4.2 Breaker Interface Module Mounted Power Supply.....	7
2-5 Communication Module (PONI) .....	8
2-6 Specification Summary.....	8
<b>SECTION 3: OPERATOR PANEL</b>	
3-1 General .....	9
3-2 LEDs.....	9
3-2.1 Operational Condition LEDs.....	9
3-2.2 Circuit Breaker Status LEDs.....	10
3-2.3 Protection Status LEDs .....	10
3-2.4 Energy Monitoring LEDs .....	11
3-3 Display Windows .....	11
3-3.1 Identification Display .....	11
3-3.2 Description Display.....	12
3-3.3 Function Display.....	12
3-4 Pushbuttons .....	12
3-4.1 Raise and Lower Pushbuttons .....	12
3-4.2 Up and Down Pushbuttons.....	12
3-4.3 Help Pushbutton.....	13
3-4.4 Escape Pushbutton .....	13
3-4.5 Select Pushbutton .....	13
3-4.6 Next Pushbutton .....	13
3-4.7 Select/Next Pushbutton Combination.....	13
3-5 Mimic Time-Current Curve .....	14

	Page
<b>SECTION 4: OPERATION</b>	
4-1 General .....	15
4-2 Security Password.....	15
4-2.1 Change Security Password .....	15
4-3 Power Application.....	18
4-3.1 Run Mode.....	18
4-3.2 Learn Mode .....	18
4-4 Configure.....	19
4-4.1 Setting Date and Time.....	20
4-4.2 Updating for Added Devices.....	20
4-4.3 Change Device Descriptions .....	21
4-4.4 Program Settings Menu.....	21
4-4.5 Program Group Menu.....	22
4-4.6 Alarms Menu .....	23
4-5 Displayed Information.....	24
4-6 Communications.....	25
4-6.1 Sub-Network Communications.....	25
4-6.2 Network Communications .....	25
4-7 Test Trip Units .....	26
<b>SECTION 5: INSTALLATION, STARTUP AND TESTING</b>	
5-1 Introduction.....	28
5-2 Panel Preparation.....	28
5-2.1 Cutout.....	28
5-2.2 Mounting.....	28
5-2.3 Miscellaneous Mounting Details .....	28
5-3 Wiring .....	29
5-4 Initial Startup .....	29
5-4.1 Before Power Application .....	31
5-4.2 Initial Power Application .....	31
<b>SECTION 6: TROUBLESHOOTING AND MAINTENANCE</b>	
6-1 Level of Repair .....	33
6-2 Troubleshooting.....	33
6-3 Replacement .....	33
6-4 Maintenance and Care .....	33
6-5 Return Procedure .....	33
6-6 Technical Assistance.....	33
APPENDIX A INSTRUCTIONAL REFERENCES .....	36

## LIST OF FIGURES

<b>Figure</b>	<b>Title</b>	<b>Page</b>
1-1	Breaker Interface Module in Service.....	2
1-2	Typical System Configurations .....	3
2-1	Breaker Interface Module Operator Panel .....	4
2-2	Breaker Interface Module (Rear View) .....	5
2-3	Breaker Interface Module (Rear Bottom View) .....	6
2-4	Communications Module (PONI) - Shown Mounted.....	6
2-5	Breaker Interface Module Terminal Block (Contacts 1-9).....	7
2-6	Breaker Interface Module Terminal Block (Contacts 10-18).....	7
3-1	Operational and Circuit Breaker Status LEDs .....	9
3-2	Protection Status and Energy Monitoring LEDs .....	9
3-3	Device Address Display.....	11
3-4	Group Display .....	11
3-5	Description and Function Displays .....	12
3-6	Main Menu Option Screens .....	12
3-7	Raise and Lower Pushbuttons.....	13
3-8	Pushbuttons Near Function Display .....	13
3-9	LED Type Mimic Time-Current Curve.....	14
4-1	Breaker Interface Module Menu Diagram.....	16
4-2	Set Password Display.....	18
4-3	Learn Display.....	18
4-4	Set Password Display .....	18
4-5	Typical Breaker Interface Module Displays .....	19
4-6	Typical Present Date Display.....	20
4-7	Set Date Display .....	20
4-8	Set Description Display .....	21
4-9	Typical Existing Description Example .....	21
4-10	Typical New Description Example .....	21
4-11	Program Settings Display .....	22
4-12	Typical Frame Size Display .....	22
4-13	No Alarms Display .....	23
4-14	Alarms Menu Display.....	23
4-15	Typical Alarms Menu Display .....	23
4-16	Typical Meter Menu Display .....	25
4-17	"Address" Raise and Lower Pushbuttons .....	25
4-18	Test Display .....	26
4-19	Phase Test Display .....	26
4-20	Trip Test Display .....	26
4-21	Typical Test Current Curve .....	26
4-22	Typical Test Time in Seconds Display .....	26
4-23	Tripped Alarm Display .....	26
5-1	Cutout Dimensions and Drilling Pattern (inches).....	28
5-2	Breaker Interface Module Dimensions (inches).....	29
5-3	Typical Network Wiring Diagram .....	30
5-4	Connections and DIP Switch Rear Label Diagram .....	31

**LIST OF TABLES**

<b>Figure</b>	<b>Title</b>	<b>Page</b>
2.1	Breaker Interface Module Specifications .....	8
4.1	Alarms Menu Messages .....	24
5.1	Operational DIP Switch Settings.....	32
6.1	Troubleshooting Guide .....	34
A.1	Instructional References .....	36

## SECTION 1: INTRODUCTION

### 1-1 COMMON TERMS

Several commonly used terms or phrases are used throughout this manual. They are defined here to eliminate any confusion that might arise when reading the text.

**IMPACC (Integrated Monitoring, Protection and Control Communications)** – A family of communicating electrical power distribution protective devices, meters, motor control devices, communications networks and protocols and software packages to provide power distribution monitoring and control.

**INCOM (Industrial Communications)** – A noise immune communications system designed specifically for power distribution monitoring and control applications.

**PONI (Product Operated Network Interface)** – A plug-in communications module that enables network communications.

### 1-2 PRELIMINARY COMMENTS AND SAFETY PRECAUTIONS

This instructional manual is intended to present specific descriptive, operational, installation and maintenance information associated with the Breaker Interface Module only. The Breaker Interface Module is compatible with Digitrip OPTIM Trip Units, Digitrip RMS 810/910 Trip Units and IQ Energy Sentinels. For a general overview of the entire Digitrip OPTIM Trip Unit System and certain specific application possibilities, refer to Instruction Book 29C890 entitled "Instructional Overview for Use Of the Digitrip OPTIM Trip Unit System."

Detailed instructional material relative to the installation, use and maintenance of specific devices is included under separate cover by a manual dedicated to each device. A series of four manuals brings together the wide array of capabilities offered by the most advanced programmable trip unit system - Digitrip OPTIM. Refer to Appendix A for all instruction material references.

Please read and understand this manual and all other relevant manuals before proceeding with the installation and operation of any device included in the trip unit sys-

tem. Pay particular attention to all **WARNINGS** and **CAUTIONS**. They are intended to help insure personnel safety and equipment protection. Refer to the **WARNING** and **CAUTION** in Paragraph 1-2.1 before proceeding to any other section in this manual or any other manual. If further information is required by the purchaser regarding a particular installation, application or maintenance activity, a Cutler-Hammer representative should be contacted.

#### 1-2.1 SAFETY PRECAUTIONS

All safety codes, safety standards and/or regulations must be strictly observed in the installation, operation and maintenance of any device in this system.



#### WARNING

THE WARNINGS AND CAUTIONS INCLUDED AS PART OF THE PROCEDURAL STEPS IN THIS DOCUMENT ARE FOR PERSONNEL SAFETY AND PROTECTION OF EQUIPMENT FROM DAMAGE. AN EXAMPLE OF A TYPICAL WARNING LABEL HEADING IS SHOWN ABOVE IN REVERSE TYPE TO FAMILIARIZE PERSONNEL WITH THE STYLE OF PRESENTATION. THIS WILL HELP TO INSURE THAT PERSONNEL ARE ALERT TO WARNINGS, WHICH MAY APPEAR THROUGHOUT THE DOCUMENT. IN ADDITION, CAUTIONS ARE ALL UPPER CASE AND BOLDFACE AS SHOWN BELOW.



#### CAUTION

COMPLETELY READ AND UNDERSTAND THE MATERIAL PRESENTED IN THIS DOCUMENT BEFORE ATTEMPTING INSTALLATION, OPERATION OR APPLICATION OF THE EQUIPMENT. IN ADDITION, ONLY QUALIFIED PERSONS SHOULD BE PERMITTED TO PERFORM ANY WORK ASSOCIATED WITH THE EQUIPMENT. ANY WIRING INSTRUCTIONS PRESENTED IN THIS DOCUMENT MUST BE FOLLOWED PRECISELY. FAILURE TO DO SO COULD CAUSE PERMANENT EQUIPMENT DAMAGE.




Figure 1-1 Breaker Interface Module in Service

### 1-3 PRODUCT OVERVIEW

The Breaker Interface Module is a comprehensive, multi-function, microprocessor-based operator interface that can be mounted locally at the device or at a remote location (Figure 1-1). In conjunction with the OPTIM Trip Unit it accomplishes the functions of individually mounted devices, such as wired ammeters, ammeter switches, watthour meters, breaker indicating lights, alarm contacts, test equipment, and programming devices. The Breaker Interface Module can monitor up to 50 devices which includes circuit breakers equipped with Digitrip OPTIM or Digitrip RMS 810/910 Trip Units, IQ Energy Sentinels and Universal IQ Energy Sentinels. The number of devices being monitored, however, cannot exceed 50 total. Like the OPTIMizer Hand Held Programmer (I.B. 29C892), the Breaker Interface Module can be used to program and test OPTIM Trip Units.

The Breaker Interface Module will communicate to multiple trip units over a sub-network, as well as a personal computer on a main network. When communicating with trip units and energy devices, the Breaker Interface Module acts as the master device. When communica-

tions is from a computer through the Breaker Interface Module via a PONI, the computer assumes the role of the master device (Figure 1-2).

The Breaker Interface Module provides the operator with all the feature capabilities of the Hand Held Programmer except for the following:

- Setting device address
- Setting BAUD rate

**Notice:** *A direct breaker connection via an OPTIMizer Hand Held Programmer will override an INCOM connection. This will cause a no response alarm on the Breaker Interface Module and a master network.*

### 1-4 FEATURES AND FUNCTIONS

An operator can use the Breaker Interface Module to:

- **Configure OPTIM Trip Unit**

- Select breaker addresses
- Select frequency (50/60 Hz)
- Set security passwords
- Change time-current setpoints
- Select protection options
- Select alarm levels

- **Display Information**

- Breaker description/status
- Time-current setpoints
- Metered values
- Trip event information

- **Test OPTIM Trip Unit Performance**

- Phase and ground
- Trip or no trip

- **Energy Monitoring**

- Set addresses for group energy monitoring
- Group energy readings
- Configure alarms on demand exceeded
- Indicate alarms via output contacts

- **Local and Remote Indication**

- Remote indication/alarming
- Breaker status indication

- **IMPACC Communications with**

- Digitrip OPTIM Trip Units
- Digitrip RMS 810/910 Trip Units
- IQ Energy Sentinels and Universal IQ Energy Sentinels
- Up to 50 devices total




Figure 1-2 Typical System Configurations