

<b>SECTION 1: INTRODUCTION/QUICK START ....</b>	<b>1-1</b>	<b>SECTION 5: OPERATION.....</b>	<b>5-1</b>
<b>1-1 Preliminary Comments And Safety Precautions .....</b>	<b>1-1</b>	<b>5-1 General .....</b>	<b>5-1</b>
1-1.1 Warranty And Liability Information .....	1-1	<b>5-2 Display Mode (“METER MENU”).....</b>	<b>5-1</b>
1-1.2 Safety Precautions.....	1-1	5-2.1 Displayed Parameters.....	5-2
1-1.3 Factory Correspondence.....	1-1	5-2.2 Displayed Sign Conventions .....	5-3
<b>1-2 Product Overview .....</b>	<b>1-1</b>	5-2.3 Display Manager.....	5-5
1-2.1 Comprehensive Information.....	1-3	<b>5-3 Help Mode .....</b>	<b>5-5</b>
1-2.2 Harmonic Distortion Analysis .....	1-3	<b>5-4 Programming MODE.....</b>	<b>5-6</b>
1-2.3 Extensive I/O And Communications Capabilities.....	1-3	<b>5-5 GENERAL SETUP .....</b>	<b>5-8</b>
1-2.4 Disturbance Information.....	1-3	5-5.1 System Type.....	5-8
1-2.5 High Accuracy .....	1-3	5-5.2 Frequency.....	5-9
1-2.6 Operational Simplicity.....	1-3	5-5.3 Incoming Line-to-Line Voltage .....	5-9
<b>1-3 Quick Start .....</b>	<b>1-4</b>	5-5.4 PT Primary Rating .....	5-9
1-3.1 Quick Start Steps.....	1-4	5-5.5 CT Primary Rating .....	5-9
<b>SECTION 2: HARDWARE DESCRIPTION.....</b>	<b>2-1</b>	5-5.6 Ground CT Primary Rating .....	5-9
<b>2-1 General .....</b>	<b>2-1</b>	5-5.7 Programming Options.....	5-9
<b>2-2 Operator Panel.....</b>	<b>2-1</b>	5-5.8 Power/Energy Options .....	5-10
<b>2-3 Rear Access Area.....</b>	<b>2-2</b>	5-5.9 Date and Time .....	5-10
2-3.1 Back of Chassis .....	2-2	5-5.10 Change Password.....	5-10
2-3.2 Left Rear of Chassis .....	2-3	5-5.11 Communication Mode .....	5-11
2-3.3 Right Rear of Chassis .....	2-3	<b>5-6 Inputs/Outputs .....</b>	<b>5-11</b>
<b>2-4 External Hardware .....</b>	<b>2-4</b>	5-6.1 Discrete Contact Inputs.....	5-11
2-4.1 Current Transformers.....	2-4	5-6.2 Analog Input .....	5-11
2-4.2 Potential Transformers .....	2-4	5-6.3 Analog Outputs.....	5-13
2-4.3 Power Supply Modules .....	2-4	5-6.4 Relay Output Contacts.....	5-16
2-4.4 Optional Communication Module .....	2-4	<b>5-7 Analysis Modes.....</b>	<b>5-18</b>
<b>2-5 Specification Summary .....</b>	<b>2-5</b>	5-7.1 Minimum/Maximum Trend Analysis .....	5-19
<b>SECTION 3: OPERATOR PANEL.....</b>	<b>3-1</b>	5-7.2 Event Analysis.....	5-20
<b>3-2 LEDs .....</b>	<b>3-1</b>	5-7.3 Harmonic Analysis .....	5-24
<b>3-3 Display Window .....</b>	<b>3-1</b>	5-7.4 Demand Analysis.....	5-24
<b>3-4 Pushbuttons.....</b>	<b>3-2</b>	<b>5-8 Communications.....</b>	<b>5-25</b>
<b>SECTION 4: INSTALLATION.....</b>	<b>4-1</b>	5-8.1 IPONI .....	5-25
<b>4-1 Introduction .....</b>	<b>4-1</b>	5-8.2 EPONI and EPONIF .....	5-25
<b>4-2 Panel Preparation .....</b>	<b>4-1</b>	5-8.3 PowerNet Software Suite .....	5-26
4-2.1 Standard flush mounted Cutout.....	4-2	5-8.4 PowerNet Graphics.....	5-26
4-2.2 Standard flush Mounting .....	4-2	5-8.5 Connectivity.....	5-26
4-2.3 Optional Flange Mounted Cutout and Mounting.....	4-3	<b>5-9 IQ Analyzer 6600 Series Graphic Displays</b>	<b>5-26</b>
<b>4-3 Wiring .....</b>	<b>4-3</b>	5-9.1 Graphic Waveform .....	5-26
4-3.1 Current and Potential Transformer Selection.....	4-5	5-9.2 Harmonic Spectrum .....	5-26
4-3.2 Wiring Diagrams.....	4-5	<b>5-10 Reset Mode.....</b>	<b>5-27</b>
<b>4-4 Initial Startup.....</b>	<b>4-5</b>	<b>5-11 Trend Data Operation (NEW!).....</b>	<b>5-28</b>
4-4.1 Before Power Application.....	4-5	5-11.1 Organization of Data .....	5-28
4-4.2 Initial Power Application.....	4-5	5-11.2 Display of Trend Data .....	5-28
<b>4-5 Quick Start Metering.....</b>	<b>4-6</b>	5-11.3 Programming of Trend Parameters.....	5-29
		5-11.4 Applications of Trending .....	5-31
		<b>5-12 Event Log Operation (NEW!) .....</b>	<b>5-33</b>
		<b>5-13 Time Of Use Energy &amp; Demand (NEW!) ....</b>	<b>5-34</b>
		5-13.1 Time of Use Displays .....	5-34
		5-13.2 Programming Time of Use Schedules.	5-35

**SECTION 6: PROGRAMMING ..... 6-1**

**6-1 Introduction..... 6-1**

**6-2 Common Programming Procedures ..... 6-1**

- 6-2.1 Entering Program Mode ..... 6-2
- 6-2.2 Password Entry..... 6-2
- 6-2.3 View Only Password ..... 6-2
- 6-2.4 Movement to Previous Levels..... 6-2
- 6-2.5 Exiting Program Mode ..... 6-3

**6-3 PROGRAMMING EXAMPLE ..... 6-3**

- 6-3.1 Programming Example Input..... 6-3

**6-4 Programming Categories..... 6-4**

- 6-4.1 Use of F1-F4 Pushbuttons..... 6-4
- 6-4.2 Programming Category Screens Trees .. 6-5
- 6-4.3 Screens Tree Details..... 6-5

**SECTION 7: TROUBLESHOOTING AND MAINTENANCE..... 7-1**

**7-1 Level of Repair ..... 7-1**

**7-2 Troubleshooting (Table 7.1)..... 7-1**

**7-3 Replacement..... 7-1**

**7-4 Maintenance and Care ..... 7-4**

**7-5 Calibration ..... 7-4**

**7-6 Return Procedure..... 7-4**

**7-7 Replacement Parts ..... 7-4**

**7-8 Technical Assistance..... 7-4**

**APPENDIX A**

- Startup Settings Sheet #1 ..... A-2
- Startup Settings Sheet #2 ..... A-4
- Startup Settings Sheet #3 ..... A-5
- Startup Settings Sheet #4 ..... A-6
- Startup Settings Sheet #5 ..... A-8
- Startup Settings Sheet #6 ..... A-16
- Startup Settings Sheet #7 ..... A-21
- Startup Settings Sheet #8 ..... A-22
- Startup Settings Sheet #9 ..... A-24
- Startup Settings Sheet #10 ..... A-26
- Glossary ..... A-31

**LIST OF FIGURES**

- Figure 1-1 IQ Analyzer (Front View)..... 1-2
- Figure 1-2 IQ Analyzer (Rear View) with optional IPONI (INCOM Product Operated Network Interface) Communication Module Installed..... 1-2
- Figure 2-1 IQ Analyzer Operator Panel..... 2-1
- Figure 2-2 IQ Analyzer (Rear Views). See Figures 4-7 and 4-8 for detailed identifications..... 2-2
- Figure 2-3 Separate Source Power Module (Shown Mounted)..... 2-3

- Figure 2-4 Self-Powered Three-Phase Power Module (Unmounted) ..... 2-3
- Figure 2-5 Communications Module – IPONI – (Mounted) ..... 2-5
- Figure 3-1 Typical Programming Screen..... 3-4
- Figure 3-2 Typical Meter Menu Screen ..... 3-4
- Figure 3-3 Typical TRND Min/Max Analysis Screen ..... 3-4
- Figure 3-4 Typical Event Analysis Screen..... 3-4
- Figure 3-5 Typical Harmonic Analysis Screen..... 3-4
- Figure 3-6 Typical Demand Analysis Screen..... 3-4
- Figure 3-7 Typical Help Screen..... 3-4
- Figure 3-8 Reset Screen ..... 3-4
- Figure 3-9 Typical Time of Use Energy Screen... 3-5
- Figure 3-10 Typical Time of Use Peak Demand.... 3-5
- Figure 3-11 Trend Analysis Menu ..... 3-5
- Figure 3-12 Typical Trend Analysis Buffers..... 3-5
- Figure 3-13 Energy Trend Example (Page 1)..... 3-5
- Figure 3-14 Energy Trend Example (Page 2)..... 3-5
- Figure 3-15 Energy Trend Example (Page 30)..... 3-5
- Figure 4-1 IQ Analyzer Dimensions and Cutout (inches [mm])..... 4-1
- Figure 4-2 Flush Mounted Drilling Pattern..... 4-2
- Figure 4-3 Power Module Dimensions ..... 4-2
- Figure 4-4 Flange Mounted Drilling Pattern..... 4-3
- Figure 4-5 IQ Analyzer Shown Mounted Using a Mounting Flange ..... 4-3
- Figure 4-6 Typical Network Wiring Diagram..... 4-4
- Figure 4-7 IQ Analyzer with Self-Powered Three-Phase Power Module (Rear View)..... 4-6
- Figure 4-8 IQ Analyzer with Separate Source Power Module (Rear View)..... 4-7
- Figure 4-9 3-phase 3-Wire (Up to 600 Volts) Wiring Diagram..... 4-8
- Figure 4-10 3-phase 3-Wire (Above 600 Volts) Wiring Diagram..... 4-8
- Figure 4-11 3-phase 3-Wire (Above 600 Volts) Wiring Diagram..... 4-9
- Figure 4-12 3-phase 4-Wire (Up to 600 Volts) Wiring Diagram..... 4-9
- Figure 4-13 3-phase 4-Wire (Above 600 Volts) Wiring Diagram..... 4-10
- Figure 4-14 3-phase 4-Wire (96 to 600 Volts) Wiring Diagram..... 4-10
- Figure 4-15 3-phase 3-Wire (Above 600 Volts) Wiring Diagram..... 4-11

Figure 4-16	3-phase 3-Wire (Above 600 Volts) Wiring Diagram .....	4-11	Figure 5-11	Faceplate Operation First Screen Selections.....	5-8
Figure 4-17	3-phase 4-Wire (96 to 600 Volts) Wiring Diagram .....	4-12	Figure 5-12	Faceplate Operation Second Screen Selections.....	5-8
Figure 4-18	3-phase 4-Wire (Above 600 Volts) Wiring Diagram .....	4-12	Figure 5-13	Download Program Screen .....	5-10
Figure 4-19	3-phase 3-Wire (Up to 600 Volts) Wiring Diagram .....	4-13	Figure 5-14	Change Date and Time Screen.....	5-10
Figure 4-20	3-phase 3-Wire (Above 600 Volts) Wiring Diagram .....	4-13	Figure 5-15	Connections for 4-20 or 0-20mA Input Signal .....	5-11
Figure 4-21	3-phase 4-Wire (Up to 600 Volts) Wiring Diagram .....	4-14	Figure 5-16	Connections for 0-5Vdc Input Signal .....	5-11
Figure 4-22	3-phase 4-Wire (Above 600 Volts) Wiring Diagram .....	4-14	Figure 5-17	Analog Output Connections 4-20 or 0-20mA.....	5-13
Figure 4-23	3-phase 3-Wire (Up to 600 Volts) Wiring Diagram .....	4-15	Figure 5-18	Relay Contact with IQ Analyzer De- energized.....	5-16
Figure 4-24	3-phase 3-Wire (Above 600 Volts) Wiring Diagram .....	4-15	Figure 5-19	Typical Relay Output Connections ...	5-16
Figure 4-25	3-phase 4-Wire (Above 600 Volts) Wiring Diagram .....	4-16	Figure 5-20	Pulse Output Connections .....	5-17
Figure 4-26	3-phase 4-Wire (96 to 600 Volts) Wiring Diagram .....	4-16	Figure 5-21	2-Wire Pulse Train.....	5-17
Figure 4-27	3-phase 4-Wire (Above 600 Volts) Wiring Diagram .....	4-17	Figure 5-22	3-Wire Pulse Train.....	5-18
Figure 4-28	Single-phase 3-Wire (Up to 600 Volts) Wiring Diagram .....	4-17	Figure 5-23	Typical Trend Analysis Screen (Ground Current maximum).....	5-19
Figure 4-29	Single-phase 2-Wire (Up to 600 Volts) Wiring Diagram .....	4-18	Figure 5-24	Typical Event #1 Screen.....	5-19
Figure 4-30	Analog Outputs.....	4-19	Figure 5-25	Typical Metered Event Voltage Screen.....	5-19
Figure 4-31	Analog Input (Auxiliary Current Input Connections) .....	4-20	Figure 5-26	Event Trigger, Delay, and Reset Thresholds.....	5-21
Figure 4-32	Analog Input (Auxiliary Current Input Connections) .....	4-20	Figure 5-27	Typical Event Voltage Disturbance Screen.....	5-22
Figure 4-33	Discrete Contact Inputs.....	4-21	Figure 5-28	Typical Transient Waveform Display on IQA6600 Series .....	5-23
Figure 4-34	Control Relay Connections .....	4-21	Figure 5-29	Typical Amps Selection Phase Screen.....	5-24
Figure 5-1	Meter Menu Initial Current Screen .....	5-2	Figure 5-30	Typical Volts A-B Screen .....	5-24
Figure 5-2	Second Meter Menu Current Screen..	5-2	Figure 5-31	Demand Analysis #1 Screen.....	5-24
Figure 5-3	Typical Power Factor Minimum/Maximum Possibilities.....	5-3	Figure 5-32	Typical Present Power Demand Screen.....	5-25
Figure 5-4	Power Quadrants, Direct Mathematical.....	5-4	Figure 5-33	Sliding Demand Setpoints Screen....	5-25
Figure 5-5	Power Quadrants, Power Engineers ..	5-4	Figure 5-34	Typical Captured Waveform .....	5-26
Figure 5-6	Induction Motor Load.....	5-4	Figure 5-35	Typical Harmonic Spectrum Display .....	5-26
Figure 5-7	Power Distribution .....	5-4	Figure 5-36	Typical Harmonic Spectrum Display .....	5-27
Figure 5-8	Display Options Screen .....	5-7	Figure 5-37	Trend Data Screen .....	5-28
Figure 5-9	First Help Menu .....	5-7	Figure 5-38	Trend Menu of 900 Byte Buffers .....	5-28
Figure 5-10	Second Help Menu .....	5-7	Figure 5-39	Trend Data Screen .....	5-29
			Figure 5-40	Trend Programming Screen.....	5-29
			Figure 5-41	Trend Items, Interval, and Memory ..	5-29
			Figure 5-42	Trend Items .....	5-30

Figure 5-43	Selecting the Trend Time Interval ....	5-30
Figure 5-44	Maximum Memory Allocation.....	5-30
Figure 5-45	Voltage Sag Waveform & Analysis ..	5-31
Figure 5-46	Periodic Record of Min/Max Values .....	5-32
Figure 5-47	Timestamp Record of Input#1 Events .....	5-33
Figure 5-48	Page 1 of Event Log Screen .....	5-33
Figure 5-49	Page 168 of Event Log Screen .....	5-34
Figure 5-50	Time Of Use Energy Display.....	5-34
Figure 5-51	Time Of Use Demand Display.....	5-34
Figure 5-52	Time Of Use Programming Screen ..	5-35
Figure 5-53	Programming TOU Clock Adjustments.....	5-35
Figure 5-54	Programming 8 TOU Seasons .....	5-35
Figure 5-55	TOU Season Selection .....	5-35
Figure 5-56	Programming 32 TOU Schedules ....	5-36
Figure 5-57	Programming the Daily Schedule.....	5-36
Figure 5-58	TOU Season Selection .....	5-36
Figure 5-59	Selecting the TOU Default .....	5-36
Figure 5-60	Download Program Screen .....	5-37
Figure 5-61	Change Date and Time Screen.....	5-38
Figure 6-1	Top Level Screen Showing Password Entry Field .....	6-2
Figure 6-2	Programming Example Flow Chart ....	6-6
Figure 6-3	Programming Mode Top Level Menu (Choose Category).....	6-13
Figure 6-4	General Setup Screens Tree.....	6-14
Figure 6-5	Analog Inputs Screens Tree.....	6-15
Figure 6-6	Analog Outputs Screens Tree .....	6-15
Figure 6-7	Discrete Inputs Screens Tree .....	6-16
Figure 6-8	Event Triggers Screens Tree .....	6-17

Figure 6-9	Relay Outputs Screens Tree .....	6-18
Figure 6-10	Demand Screens Tree .....	6-19
Figure 6-11	Display Manager Screens Tree .....	6-19
Figure 6-12	Trend Settings Screens Tree.....	6-20
Figure 6-13	Time of Use Settings Screens Tree..	6-21

#### LIST OF TABLES

Table 1.1	IQ Analyzer Order Information .....	1-5
Table 2-1	IQ Analyzer Specifications and Details Summary .....	2-6
Table 5.1	Meter Menu Displayed Information.....	5-2
Table 5.2	Custom Screen/Trend Parameters .....	5-5
Table 5.3	Display Options.....	5-6
Table 5.4	Analog Output Parameters.....	5-12
Table 5.5	Analog Output Combinations .....	5-14
Table 5.6	Typical Relay Application Possibilities.....	5-16
Table 5.7	Min/Max Trend Analysis Parameters .....	5-19
Table 5.8	Event Conditions.....	5-20
Table 6.1	Programming Categories .....	6-1
Table 6.2	F1-F4 Pushbutton Functions During Password Entry .....	6-2
Table 6.3	F1-F4 Pushbutton Functions During Programming .....	6-4
Table 6.4	Startup Settings Sheets Excerpts.....	6-5
Table 7.1	Troubleshooting Guide.....	7-2