

Appendix A: Device Objects

Overview

Each IMPACC device has information concerning data, control options, and setpoints. This information is available through specific PowerNet Software applications, through Dynamic Data Exchange (DDE), or through a NetPower DeviceServer. With this information, you can program DDE applications or map Modbus registers.

Information about monitoring and controlling is listed by device in device object tables, which are found in *Appendix B: Device Objects* in the *PowerNet Software User's Guide*.

