



Programmable Controls

PC-1100/1200 Programmable Controller Systems Manual

Westinghouse Electric Corporation
Automation Division
200 Beta Drive
Pittsburgh, PA 15238

January, 1989

WARNING

THIS EQUIPMENT HAS NOT BEEN TESTED TO SHOW COMPLIANCE WITH NEW FCC RULES (47 CFR, PART 15) DESIGNED TO LIMIT INTERFERENCE TO RADIO AND TV RECEPTION. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE UNACCEPTABLE INTERFERENCE TO RADIO COMMUNICATION, REQUIRING THE OPERATOR TO TAKE WHATEVER STEPS ARE NECESSARY TO CORRECT THE INTERFERENCE.

Since the equipment explained in this manual has a variety of uses, the user and those responsible for applying this equipment must satisfy themselves as to the acceptability of each application and use of the equipment. Under no circumstances will Westinghouse Electric Corporation be responsible or liable for any damage, including indirect or consequential losses resulting from the use, misuse, or application of this equipment.

The text, illustrations, charts, and examples included in this manual are intended solely to explain the use and application of the Westinghouse unit(s). Due to the many variables associated with specific uses or applications, Westinghouse Electric Corporation cannot assume responsibility or liability for actual use based upon the data provided in this manual.

No patent liability is assumed by Westinghouse Electric Corporation with respect to the use of circuits, information, equipment, or software described in this manual.

No part of this manual may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, including electronic, mechanical, photocopying or otherwise, without the prior express written permission of Westinghouse Electric Corporation.

This manual is printed in the U.S.A. and is subject to change without notice.

PEM is a trademark of PEM Corporation.
NOVRAM is a trademark of XICOR Corporation.
Memory Safe is a trademark of Westinghouse Electric Corporation.

THUMB TAB INDEX
PC-1100/1200 Systems Manual (NLAM-B206)

SECTION 1. INTRODUCTION

SECTION 2. SYSTEM OVERVIEW

SECTION 3. INSTALLATION AND START-UP

SECTION 4. PROGRAMMING APPROACH

SECTION 5. SPECIAL FUNCTIONS

SECTION 6. TROUBLESHOOTING

APPENDIX A. GLOSSARY

APPENDIX B. SPECIFICATIONS

APPENDIX C. MODULE ADDRESSING DETAILS




TABLE OF CONTENTS

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
SECTION 1. INTRODUCTION TO THE PC-1100/1200		
1-1	General Description.....	1-1
1-2	PC-1100/1200 Family of Controllers.....	1-1
1-3	Scope.....	1-3
1-4	Unpacking Procedures.....	1-3
1-5	Storage.....	1-3
1-6	Reference Manuals.....	1-4
SECTION 2. SYSTEM OVERVIEW		
2-1	Basic Control System.....	2-1
2-2	PC-1100/1200 Programmable Control System.....	2-2
2-3	Controller.....	2-3
2-4	Memory.....	2-4
2-5	Processing Circuitry.....	2-5
2-6	I/O Servicing.....	2-6
2-7	Power Supplies.....	2-7
2-8	Controls and Indicators.....	2-7
2-9	Controller Connections.....	2-9
2-10	Specifications and Performance Data.....	2-10
2-11	1000 Series I/O.....	2-12
2-12	Input Modules.....	2-12
2-13	Output Modules.....	2-16
2-14	I/O Racks.....	2-20
2-15	Field Wiring.....	2-29
2-16	I/O Power Requirements.....	2-29
2-17	Peripheral Equipment.....	2-32
2-18	Advanced Program Loader.....	2-32
2-19	CRT Program Loader.....	2-33
2-20	Mini Loader.....	2-33
2-21	Printer.....	2-34
2-22	Tape Loader.....	2-35
2-23	Memory Safe™ Program Cartridge.....	2-35
2-24	Peripheral Compatibility.....	2-38
SECTION 3. INSTALLATION AND STARTUP		
3-1	Installation Overview.....	3-1
3-2	Recommended Installation Technique.....	3-1
3-3	Unpacking Instructions.....	3-2
3-4	Electrostatic Discharge.....	3-2
3-5	Controller Power-Up Check.....	3-3

TABLE OF CONTENTS (Cont'd)

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
SECTION 3. INSTALLATION AND STARTUP, CONT'D		
3-6	Enclosure and Panel Selection.....	3-8
3-7	Layout Considerations.....	3-9
3-8	Field Wiring Considerations.....	3-12
3-9	I/O Screw Terminal Connection And Wire Routing.....	3-12
3-10	Grounding Considerations.....	3-12
3-11	Suppression Requirements and Techniques.....	3-17
3-12	Rack Density Considerations.....	3-20
3-13	Rack, Controller, and Module Installation.....	3-20
3-14	Rack Mounting.....	3-21
3-15	Controller and I/O Module Installation.....	3-24
3-16	I/O Module Wiring.....	3-39
3-17	Controller Configuration.....	3-41
3-18	Changing the Watchdog Timer Timeout Period (PC-1200).....	3-50
3-19	Disabling the On-Line Programming Function.....	3-51
3-20	Networking.....	3-53
3-21	Serial Port Definition.....	3-58
3-22	System Testing.....	3-62
3-23	I/O Module Testing.....	3-63
3-24	Peripheral Testing.....	3-65
3-25	Program Verification.....	3-67/68
3-26	Test Failures.....	3-67/68

SECTION 4. PROGRAMMING APPROACH

4-1	General Description.....	4-1
4-2	Reference Ladder Diagrams.....	4-1
4-3	Programming Considerations.....	4-4
4-4	Conduction Within Ladder Circuits.....	4-5
4-5	Construction Guidelines.....	4-5
4-6	Labeling Scheme Guidelines.....	4-11
4-7	Contacts.....	4-12
4-8	Memory and Register Use.....	4-17
4-9	Scan Times.....	4-19
4-10	Coil Utilization.....	4-19
4-11	Dummy Coils.....	4-22
4-12	Rapid Clocking.....	4-22
4-13	Transitional Functions.....	4-23
4-14	Program Order.....	4-24
4-15	Multiple Programs.....	4-26

TABLE OF CONTENTS (Cont'd)

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
SECTION 5. SPECIAL FUNCTIONS		
5-1	Introduction.....	5-1
5-2	Special Function Descriptions.....	5-2
5-2	A Note About the LT (Literal) Function.....	5-2
	AD/SB - Add/Subtract.....	5-5
	AM - AND Matrix.....	5-10
	AR - ASCII Receive (PC-1100 Version).....	5-15
	AR - ASCII Receive (PC-1200 Version).....	5-20
	AS - Ascending Sort.....	5-25
	AT - ASCII Transmit.....	5-30
	BD/DB - Conversions.....	5-47
	BF - Bit Follow.....	5-50
	BO - Bit Operate.....	5-52
	BS/SC - Latches.....	5-57
	BT - Block Transfer.....	5-60
	CG - Continuous Group Select.....	5-64
	CM - Complement Matrix.....	5-66
	CP - Configure Port.....	5-71
	CR - Control Relay.....	5-78
	DV - Divide.....	5-81
	EQ/GE - Comparison.....	5-86
	FI/FO - FIFO Stack.....	5-90
	FI/LO - FILO Stack.....	5-96
	IM - Indirect Move.....	5-102
	LC - Loop Controller.....	5-107
	LR - Latch Read.....	5-164
	LS - Lock Scan.....	5-169
	LT - Literal.....	5-175
	MB - Move Byte.....	5-179
	MP - Multiply.....	5-184
	MR - Master Control Relay.....	5-188
	MV - Move.....	5-191
	NR/NL - N Bit Serial Shift Registers.....	5-194
	OM - OR Matrix.....	5-201
	OT/CT - Open Table/Close Table.....	5-207
	PT - Port Transmit.....	5-212
	RP - Restore Program Counter.....	5-232
	RW - Reset Watchdog Timer.....	5-238
	SK - Skip.....	5-243
	SM - Search Matrix.....	5-246
	SP - Save Program Counter.....	5-251
	SQ - Square Root.....	5-253

TABLE OF CONTENTS (Cont'd)

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
SECTION 5. SPECIAL FUNCTIONS, CONT'D		
	TL/TO - Table Lookup/Table Lookup Ordered.....	5-259
	TR - Table-to-Register Move.....	5-263
	TS/TT - Timers.....	5-269
	UA - Unit Address.....	5-275
	UC/DC - Counters.....	5-278
	UI - I/O Update Immediate.....	5-282
	US - Update Select.....	5-285
	XM - XOR Matrix.....	5-288
	Battery Status Coil.....	5-293/294

SECTION 6. TROUBLESHOOTING

6-1	Introduction.....	6-1
6-2	Troubleshooting Approach.....	6-3
6-3	Complete Failure.....	6-3
6-4	Partial Failure.....	6-3
6-5	Common Failures.....	6-4
6-6	Program Loader Diagnostic Capabilities.....	6-4
6-7	Front Panel Controls and Indicators.....	6-5
6-8	Power Supply Fuse.....	6-7
6-9	Battery Replacement.....	6-8
6-10	Fault Register Data.....	6-11
6-11	Pre-Check Procedure.....	6-11
6-12	Fault Register Interpretation.....	6-11
6-13	Communications Error.....	6-12

APPENDIX A. GLOSSARY

APPENDIX B. CONTROLLER SPECIFICATIONS

APPENDIX C. MODULE ADDRESSING DETAILS

TABLE OF CONTENTS (Cont'd)

List of Illustrations

<u>Figure</u>	<u>Title</u>	<u>Page</u>
SECTION 2. SYSTEM OVERVIEW		
2-1	Three Sections of Any Control System.....	2-1
2-2	Relay-type Control System.....	2-1
2-3	Three Sections of a Programmable Controller.....	2-2
2-4	Basic PC-1100/1200 System.....	2-3
2-5	Simplified PC-1100/1200 Controller Block Diagram.....	2-4
2-6	PC-1100/1200 Controls and Indicators.....	2-8
2-7	PC-1100/1200 Connector Identification.....	2-9
2-8	Program Loader Port and Computer Port.....	2-9
2-9	Typical Discrete I/O Module.....	2-13
2-10	Terminal Block Removal.....	2-14
2-11	Example PC-1100/1200 System Configuration (Using NLR-1008, NL-1076, and NLRE-1009/1011).....	2-22
2-12	Example PC-1100/1200 Configuration (Using NLR-1008, Two NL-1076s, and Two NLRE-1009/1011s).....	2-23
2-13	Example PC-1200 Configuration (Using NLR-1008, Four NL-1076s, and Four NLRE-1009/1011s).....	2-24
2-14	Example PC-1200 Configuration (Using NLR-1008, NL-1077, and Two NLRE-1011Bs).....	2-25
2-15	Example PC-1200 Configuration (Using NLR-1008, Two NL-1077s, and Two NLRE-1011Bs).....	2-26
2-16	Example PC-1200 Configuration (Using NLR-1008, Three NL-1077s, and Five NLRE-1011Bs).....	2-27
2-17	Example PC-1200 Configuration (Using NLR-1016, NL-1077, and NLRE-1017).....	2-28
2-18	CRT Program Loader.....	2-33
2-19	Mini Loader.....	2-34
2-20	Attaching Memory Safe Cartridge to Controller.....	2-36
2-21	Memory Safe Program Cartridge.....	2-37

SECTION 3. INSTALLATION AND STARTUP

3-1	PC-1100 Battery Backup Activation.....	3-4
3-2	PC-1200 Battery Backup Activation.....	3-4
3-3	Selection of 240 VAC Operation.....	3-5
3-4	Temporary AC Line Cord Connection.....	3-5
3-5	Temporary DC Line Cord Connection.....	3-6
3-6	Typical NEMA Type 12 Enclosure Used with PC-1100/1200.....	3-8
3-7	Vertical Separation Between Primary and Expansion I/O Racks.....	3-10
3-8	System Layout (Typical).....	3-12
3-9	Field Wiring to Terminal Block.....	3-13
3-10	Typical PC-1100/1200 System Power Wiring.....	3-14
3-11	Component Mounting Methods.....	3-16
3-12	Relay, Valve, and Solenoid Suppression Example.....	3-17

TABLE OF CONTENTS (Cont'd)

List of Illustrations (Cont'd)

<u>Figure</u>	<u>Title</u>	<u>Page</u>
SECTION 3. INSTALLATION AND START-UP, CONT'D		
3-13	A200 Starter and Large Inductive Device Suppression Example.....	3-18
3-14	Motor Suppression Example.....	3-18
3-15	Input Converter and AC Output Suppression.....	3-19
3-16	Layout Dimensions for 4-Module Rack (NLR-1004).....	3-22
3-17	Layout Dimensions for 8-Module Rack (NLR-1008) or 9-Module Expansion Rack (NLRE-1009/1011/1011B).....	3-22
3-18	Layout Dimensions for 12-Module Rack (NLR-1012) or 13-Module Expansion Rack (NLRE-1013).....	3-23
3-19	Layout Dimensions for 16 Module Rack (NLR-1016) or 17-Module Expansion Rack (NLRE-1017).....	3-23
3-20	Controller and Module Insertion.....	3-24
3-21	Controller/Module Mounting.....	3-25
3-22	Controller I/O Image Table.....	3-27
3-23	I/O Module Addresses and I/O Image Table.....	3-28
3-24	8-Point Discrete I/O Addressing for the NLR-1004, NLR-1008, and NLRE-1009.....	3-32
3-25	8-Point Discrete I/O Addressing for the NLR-1012 and NLR-1016 (Low Bus Only).....	3-33
3-26	8-Point Discrete I/O Addressing for the NLRE-1011B, -1013, and -1017 (Low Bus Only).....	3-34
3-27	8-Point Discrete I/O Addressing for the NLRE-1011B, -1013, and -1017 (High Bus).....	3-35
3-28	Example PC-1200/1250 Addressing (Using NLR-1008 and Two NLRE-1011Bs).....	3-36
3-29	Example PC-1200/1250 Addressing (Using NLR-1016 and NLRE-1017).....	3-37
3-30	Example PC-1200/1250 Addressing (Using NLR-1008 and Five NLRE-1011Bs).....	3-38
3-31	12-Position Terminal Block Extended.....	3-39
3-32	Typical Wiring.....	3-41
3-33	Front Panel Screws.....	3-42
3-34	PC-1100 DIP Switch Locations.....	3-43
3-35	PC-1100 Communications Expansion Board.....	3-46
3-36	PC-1200 DIP Switch Locations.....	3-47
3-37	Changing the Watchdog Timer Timeout Setting.....	3-50
3-38	Disabling the On-line Programming Function (PC-1100).....	3-52
3-39	Disabling the On-line Programming Function (PC-1200).....	3-52
3-40	Typical PC-1100/1200 RS-485 Network.....	3-54
3-41	Example RS-485 Network Connections.....	3-56
3-42	Typical Multipoint Modem Setup.....	3-57
3-43	Analog Input Testing Circuit.....	3-62
3-44	Test Program.....	3-66

TABLE OF CONTENTS (Cont'd)

List of Illustrations (Cont'd)

<u>Figure</u>	<u>Title</u>	<u>Page</u>
SECTION 4. PROGRAMMING APPROACH		
4-1	Input Devices Shown as Contacts.....	4-2
4-2	Outputs Shown as Coils.....	4-3
4-3	Special Function Block with Multiple Contact Circuits.....	4-3
4-4	Controller Scanning.....	4-5
4-5	Circuit Conduction.....	4-6
4-6	Rule 1: Contacts Must Occur in Horizontal Branches.....	4-7
4-7	The Addition of Two Contacts Adds Path D to C to B.....	4-8
4-8	Rule 2: Branches Should Run Vertically.....	4-8
4-9	Rule 3: Contacts Should Be Connected to the Topmost Available Junctions.....	4-9
4-10	Rule 4: 10 X 7 Contact Area for Coils.....	4-10
4-11	Rule 5: 8 X 7 Contact Area for Special Functions.....	4-10
4-12	Example of Two Legal Paths.....	4-10
4-13	Example of an Illegal Path.....	4-11
4-14	Contact Types.....	4-14
4-15	Program/Register Memory Assignment.....	4-18
4-16	Dummy Coil Circuit.....	4-22
4-17	Rapid Clocking Circuit.....	4-22
4-18	Every Scan Operation.....	4-24
4-19	Improper Program Order.....	4-25
4-20	Correct Program Order.....	4-25
4-21	Table-to-Register Pitfalls.....	4-26
4-22	Multiple Programs.....	4-27

SECTION 6. TROUBLESHOOTING

6-1	Controller Front Panel Controls and Indicators.....	6-6
6-2	Power Supply Fuse Replacement.....	6-8
6-3	Replacing Backup Batteries (PC-1100).....	6-9
6-4	Replacing Backup Battery (PC-1200).....	6-10
6-5	Fault Register.....	6-12

List of Tables

<u>Table</u>	<u>Title</u>	<u>Page</u>
SECTION 1. INTRODUCTION TO THE PC-1100/1200		
1-1	PC-1100 Models.....	1-2
1-2	PC-1200 and -1250 Models.....	1-2
1-3	I/O Modules and Other Components.....	1-4

TABLE OF CONTENTS (Cont'd)

List of Tables (Cont'd)

<u>Table</u>	<u>Title</u>	<u>Page</u>
SECTION 2. SYSTEM OVERVIEW		
2-1	Panel Controls and Indicators.....	2-8
2-2	Discrete Input Modules.....	2-14
2-3	Analog Input Modules.....	2-15
2-4	Register Input Module.....	2-16
2-5	Discrete Output Modules.....	2-17
2-6	Analog Output Modules.....	2-18
2-7	Register Output Module.....	2-18
2-8	Relay Output Module Parameters.....	2-19
2-9	Controller, Expansion Racks, and RBE Combinations.....	2-21
2-10	1000 Series Module Power Requirements.....	2-30
2-11	NLE-1070 Expansion Power Supply Characteristics.....	2-31
SECTION 3. INSTALLATION AND STARTUP		
3-1	I/O Racks.....	3-21
3-2	PC-1100 DIP Switch Positions.....	3-44
3-3	PC-1200 DIP Switch Positions.....	3-47
3-4	Port B Switch Settings (PC-1200).....	3-49
3-5	Watchdog Timer Timeout Period Selection.....	3-51
3-6	PC-1100/1200 to AT&T 202T Modem Cable.....	3-57
3-7	PC-1100/1200 "D" Connector Signal Lines.....	3-59
3-8	NL-1075/1075B Signal Lines - Port A (RS-232).....	3-60
3-9	NL-1075/1075B Signal Lines - Port B (RS-232).....	3-60
3-10	NL-1075/1075B Signal Lines - Port B (RS-485).....	3-60
SECTION 4. PROGRAMMING APPROACH		
4-1	Reference Number Assignment.....	4-13
4-2	Contact Operating Data.....	4-15
4-3	Contact Reference Numbers.....	4-16
4-4	Scan Times.....	4-20
SECTION 5. SPECIAL FUNCTIONS		
5-1	Special Functions.....	5-3
SECTION 6. TROUBLESHOOTING		
6-1	Fault Register Interpretation.....	6-13
APPENDIX B. CONTROLLER SPECIFICATIONS		
B-1	PC-1100/1200 Specifications.....	B-1